## Adapters for Thermostatic Flow Controls

## Ammark, Bell & Gossett/Tour & Andersson, Danfoss, Taco/Heimeier

Ammark Corporation offers a variety of adapters for the replacement of thermostatic flow controls sold by other TRV companies, as well as for Ammark. The adapters provide a simple and inexpensive changeover solution: retain the current thermostatic radiator valves (if still operational) and replace the control sensors with the proper style Ammark controls:

**Temperature Sensing**: Type 62 or 62P Self-Contained Head

Type 63 or 63XL Remote Sensing
Type 66 or 66L Remote Dial/Sensing

Electric: Type 68 DDC 24V AC, 0-10 V DC

Type 69 24 V AC

Water Sensing: Type 62C20 Self-Contained 77-140° Range

Type 63C20 Pipe Contact 68-122° Range Type 63C40 Pipe Contact 104-158° Range

All adapters are made of nickel-plated brass.

When it is time to replace the old valves, the Ammark Type 6 Series valves can be installed and the adapter discarded to allow the Ammark controls to operate with new Ammark valves.



	Part #	Description
	ADAPT	Adapter—Ammark. Adapter allows any Ammark Type 6 control to be mounted on any Ammark Type 7 thermostatic radiator valve.
	ADAPT-BG	Adapter—Bell & Gossett / Tour & Andersson.  Adapter allows any Ammark Type 6 Control to be mounted on any Bell & Gossett or Tour & Andersson thermostatic radiator valve.
	ADAPT-DANF	Adapter—Danfoss. Adapter allows any Ammark Type 6 Control to be mounted on any Danfoss Model RA 2000 thermostatic radiator valve.
3	ADAPT-TACO	Adapter— Taco / Heimeier. Adapter allows any Ammark Type 6 Control to be mounted on any Taco/Heimeier thermostatic radiator valve.

Ammark Corporation, 230 West Parkway, Unit 12, Pompton Plains NJ 07444 Phone: 800-937-0426 Fax: 973-616-0246 Email: sales@ammarkcorp.com www.ammarkcorp.com